



Manufacturers and distributors
of quality chassis, suspension, driveline
and components

INFO & TECH: (561) 863-2188
ORDERS ONLY: (800) 327-9402
FAX: (561) 863-1424

68 to 76 B- Body Mopar

PART # 3651N

The installation of these subframe connectors on B-Body mopars is relatively simple and requires only the use of a welder, grinder, jack stands and a jack. Certain safety precautions must be taken to prevent personal injury or damage to the car.

- 1...Never work under a car that is only supported by a jack. Always use jack stands when working under any vehicle.
- 2...Never weld in the vicinity of fuel lines, brake lines, gas tank or any other flammable items. Either reposition or remove these items before welding.

Installation

- 1...Jack up the car to a good working height and support with jack stands.
- 2...Hold the connectors in place to check for fit and placement. The end that is mandrel bent goes to the front of the car and the welded end goes to the rear of the car. It may be necessary to remove the factory line clamps holding the fuel and brake lines for proper positioning before welding. The connectors should fit flush with the front and rear factory sub frames. Grind to fit if necessary.
- 3...Prepare the factory sub frames for welding by removing all the under coating, dirt and rust with the grinder. Be sure to remove the factory galvanized coating. It's very important to remove this coating to assure a proper weld.
- 4...Remove all carpet and padding in the car where the welding will be done.
- 5...Tack weld the connectors in place to check for any interference between the connectors and any factory or after market components. Finish welding the connectors in place. Weld all the way around both ends for maximum strength.
- 6...After cooling, spray on undercoat or paint to prevent rust or corrosion. Re-attach any components that were removed or reposition for welding.