



Manufacturers and distributors  
of quality chassis, suspension, driveline  
and components

INFO & TECH: (561) 863-2188  
ORDERS ONLY: (800) 327-9402  
FAX: (561) 863-1424

# Window Installation Kit

**Part #** 4912 (1/4")  
4913 (3/8")

## **Parts List:**

15... feet of rubber space  
50...Stainless Lock Nuts  
50...Stainless Bolts

**Note:** This kit will install one window

- 1...Remove the old window from the car and clean the window track of all window mounting material from the old window. The track must be clean enough for weather adhesive to stick.
- 2...Glue the rubber spacer into the window track using a good weather adhesive.
- 3...Fit the window to the opening. Mark out all of the mounting bolt holes on the window using tape along the edge of the window so a pen can be used. Check that you can get to the back of all the bolt to install the nuts. If there are some that you can not get to go ahead and rearrange the hole spacing so all of the nuts can be installed.
- 4...Drill the mounting holes for the window using a 3/16" drill bit. Drill slow going through the rubber. Countersink all of the mounting holes to fit the heads of the bolts.
- 5...Clean all the materail between the window and the rubber spacer before mounting the window.
- 6...Bolt the window in place. Do not over tighten the bolts.