



Manufacturers and distributors
of quality chassis, suspension, driveline
and components

INFO & TECH: (561) 863-2188
ORDERS ONLY: (800) 327-9402
FAX: (561) 863-1424

Offset Spring Hangers

PART # 3743

- 1... Remove the gas tank**
- 2...Unbolt the rear end housing from the spring. Lower the rear end to the ground by unbolting the rear spring hanger.**
- 3...Bolt on the new hangers by placing the dimpled end of the hanger into the stock frame where the rubber bushings used to be. Put the square dimpled bushing on the other side and bolt in place with the bolts supplied in the kit.**
- 4...With the hangers in place drill and bolt the end of each hanger to the stock floor. These bolts are not included in the kit. Use a minimum of (2) 5/16" bolts on each side. A spacer may be needed between the floor and hanger to keep it level.**
- 5...Loosen the three bolts that hold the front spring perch to the car and swing the rear of the spring under the new hanger. The springs should not be forced into place. Enlarging the holes or bending down the tabs may be necessary.**
- 6...Hang the spring into the new hangers using the stock rubber bushings and bolts. The rubber bushings may need to be sanded to fit the new hangers.**
- 7..Tighten up all the bolts that where loosened.**
- 8...The stock gas tank must be notched if it going to be used.**